
PATROL¹ - 101

WEATHERPROOF CURTAIN PIR & MW DETECTOR FOR OUTDOOR USE



GSN Electronic Company Ltd.

PATROL-101 combined detector designed for use in open, outdoor areas and low-temperature environments to -55°C.

PATROL-101 creates a narrow protective curtain allowing free movement within the protected area without triggering the alarm.

PATROL-101 with anti-mask technology, to detect all types of masking attempts.

PATROL-101 provides pet immune detection up to 30kg.

FEATURES

- DUAL TECHOLOGY PIR & MW
- QUAD ELEMENT PYRO SENSOR
- BUILT-IN HEATER
- SHOCK SENSOR
- ANTI-MASK PROTECTION
- DOPPLER PULSE-COUNT SELECTION (1-7)
- INDIVIDUAL PIR / MW/ ANTI-MASK SENSITIVITY ADJUSTMENT
- IMMUNE TO PETS UP TO 30KG
- AUTOMATIC TEMPERATURE COMPENSATION
- VISIBLE LIGHT DISTURBANCE PROTECTION
- DOUBLE RFI/EMI PROTECTION


3

• WEATHERPROOF HOUSING


DETECTOR INSTALLATION MANUAL

- **1.** Run the installation wire through the bracket wiring hole.
- 2. Mount bracket onto the wall and affix with screws, using the knockouts.

Corner installation Wall installation



- **3.** Run the installation wire through detector back cover.
- **4.** Mount back cover of the detector to the bracket using four screws
- **5.** Insert the PCB and connect wires according to the schematic.
- **6.** Close front cover and affix with screw.



5

TERMINAL BLOCK CONNECTION

+12V- TAMPER RELAY1 RELAY2 +12V-(H)

Terminals **Í** +12V-**Í** – for connection to the power supply of the control unit.

Terminals Í TamperÎ — for connection to a 24-hour normally closed protective zone in the control unit.

Terminals Í Relay 1Î – PIR detector relay output.

Terminals Í Relay 2Î – anti-mask relay output.

Terminals +12V- (H) – heater power connects to external 12-16V/1A power unit.

IMPORTANT!

When connecting the heater, take into consideration voltage drop and power loss in cables.


PATROL-101 MOUNTING OPTIONS


Detector can be installed vertically or horizontally (see illustration).


Recommended installation height is **2.5m**. Maximum installation height is **5m**.


* For installation over **3.5m**, mount the detector at an angle of **20** degrees.

NOTE! Avoid installing detector where direct sunlight can enter the pyro sensor.









6 7


1


SHOCK SENSOR

PATROL-101 includes a shock sensor that detects external attack. Any physical impact or attempt to separate the detector from the wall will trigger an alarm signal to the control panel through the terminal «TAMPER».

Jumper W5 enables/disables the shock sensor.

- Sensor activated.
- Sensor disabled.





2

1. POWER SUPPLY CONNECTION

- 2. JUMPER TO SELECT NC/NO
- 3. MW SENSITIVITY ADJUSTMENT
- 4. SHOCK SENSOR
- 5. ON/OFF SHOCK SENSOR **JUMPER**
- 6. ANIMAL WEIGHT JUMPER
- 7. ON/OFF LED JUMPER
- 8. PIR SENSITIVITY ADJUSTMENT
- 9. OPERATING MODE SETTING
- 10. ANTI-MASK SENSITIVITY **ADJUSTMENT**
- 11. PULSE PROGRAMMING **JUMPER**
- 12. MW ANTENNA
- 13. HEATER POWER SUPPLY CONNECTION
- 14. ANTI MASK RELAY OUTPUT (RELAY 2)

13

15. PIR DETECTOR RELAY OUTPUT (RELAY 1)

PIR ADJUSTMENT

- 1. Remove the front cover.
- 2. Connect the power and wait for LED to stop flashing (warm-up time 50 sec).
- 3. Set Jumper W1 to the "PIR TEST" position, RELAY 1 is open.
- 4. Replace the cover.
- 5. Use the "PIR SENSITIVITY" potentiometer to adjust the PIR sensitivity, moving within the protected area. The red LED should flash with each step.

14

MW ADJUSTMENT

- Remove the front cover.
- 2. Set Jumper W1 to the "MW TEST" position, RELAY 1 is open.
- 3. Replace the cover.
- 4. Use the "MW SFNSITIVITY" potentiometer to adjust the MW sensitivity, moving within the protected area. The blue LED should flash with each step.

11

OPERATION MODE

- 1. Set Jumper W1 to "WORK" position.
- 2. Set Jumper W6 according to animal weight.
- 3. Replace the cover LED will blink. At the same time. keep the detector field-of-view clear, until the LED stops blinking – the anti-mask function will then be activated correctly.

Use the "ANTIMASK SENSITIVITY" potentiometer to adjust anti-mask sensitivity.

4. Affix the cover with screw.

CHANGING RELAY SWITCH CONNECTIONS

- 1. Disconnect the power.
- 2. Set Jumper W4 to "ON" position.
- 3. Restore power.

PULSE-COUNTING METHOD

Selectable pulse count 1, 2, 3, 4 5. 6 or 7 provides users with the option of optimizing detector sensitivity to suit the environment, thus retaining reliable performance at all times. To adjust pulse count for specific operating environments:

- 1. Remove Jumper W3. The blue LED blinks indicating that pulse counting has begun.
- 2. Replace Jumper W3 during pause between LED blinking.

TECHNICAL SPECIFICATIONS

Input voltage9 – 16V
Current consumption: In standby mode:80mA In alarm mode:120mA
Heater input voltage12 – 14V
Heater current consumption:700mA
Microwave frequency:10.525GHz
Anti-mask startup (boot) period: 50 ± 5sec
Adjustable mask detection:0.2 –20cm
Warm up period:50 ± 5sec
Detection range:15meters
Detection speed range:0.2 – 4 m/sec
Relay output:NC/NO; 60V; 100mA; 16Ω
Tamper output:

.....NC; 60V; 100mA; 16Ω

Anti-mask Relay output:....NC/NO: 60B: 100mA: 16Ω Anti-mask alarm activation delay:.....40-60sec Alarm period:.....3sec Reset time:.....5 ± 1sec Pulse counting:.....1 – 7 Installation height:.....2.5 – 5m Light immunity:.....no less than 30000 lux Operating temperature range: without heater-30°C +60°C with heater - 55°C +60°C Storage temperature range:.... - 60°C - +80°C Protection rating.....IP65 RFI immunity: 30V/M at a frequency range 30MHz-2GHz EMI immunity......50,000V Dimensions:55mm x 49mm x 153mm Weight:.....270gr.

WARRANTY:

GSN Electronic Company Ltd. warrants the product to be free from defects in materials and workmanship under condition of observance of service regulations and to be repaired or replaced under absence of mechanical damages for a limited period of five years from the date of sale.

15

P/N: USMEPAT101REV.A

17 18 16